

070-1000 8mm Hoop Strike



Shown With Backer Mount Plate (not included)

The 070-1000 8mm Hoop Strike is designed as a companion part for use with TriMark's single rotor latches that requires an 8mm diameter strike and compliance to FMVSS 206 (ECE R11).

FEATURES/BENEFITS:

- Automotive style hoop-type strike features low profile and minimizes clothing snag hazard
- Base mounted style provides a rigid base for strike support
- Welded construction and heat treat exceeds FMVSS 206 (ECE R11) loads

Global Locations:

TriMark Corporation
500 Bailey Avenue
P.O. Box 350
New Hampton, Iowa 50659
United States
Tel: 641-394-3188
Fax: 641-394-2392
1-800-447-0343
www.trimarkcorp.com

TriMark Europe
Cedar Court
Walker road
Bardon Hill
Coalville LE67 1TU
United Kingdom
Tel: +44(0)1530 512460
Fax: +44(0)1530 512461
www.trimarkeu.com

TriMark (Xuzhou)
Building A5 Jingwu Road
Xuzhou Economic
Development Zone
Xuzhou, Jiangsu
221004 PR China
Tel: +86 516 8773 0018
Fax: +86 516 8773 0058
www.trimarkcn.com



TriMark. Interactive. Product. Selector



TriMark



TriMark Corporation

AVAILABLE:

- 43mm high x 57mm long base
- Other versions available; please inquire
- Backer mount plate is available to facilitate strike mounting and adjustability (P/N 35285) (not included)

MATERIAL:

- Hoop material is medium carbon steel, heat treated for strength and long life

INSTALLATION:

- (2) M6 x 1 class 10.9 flat head fasteners are required (not included)
- Tighten to the fastener manufacturers' recommended torque value, however, do not exceed 135 in-lbs (15.0 N-m)
- It is recommended that the hoop strike is mounted to the aperture with the TriMark Backer Mount Plate corresponding to hoop strike (P/N 35285) (not included)
- **Note:** Aligning the latch and the hoop strike is KEY to proper latch function

FINISH:

- Zinc plated with clear chromate
- Black e-coat

LATCH & HOOP STRIKE INSTALLATION:

- Install hoop strike in door frame (It is recommended to use TriMark Backer Mount Plate on the inside of the door jamb to facilitate mounting and adjustability (Part # 35285) (not included)
- Close door carefully and check for interference between head of hoop strike and latch components
- Adjust hoop strike vertically so door is not guided upward or downward while being closed (See AP050-1900 Application Guide)
- CHECK TO DETERMINE THAT BOTH SECONDARY AND PRIMARY LATCHING POSITIONS ARE USABLE
- Door should be latched but not "closed" in secondary position and latched to anticipated "closed" position with respect to adjacent surfaces in primary position
- If both primary and secondary positions are not evident, readjust hoop strike
- After installation, check door alignment and door seal pressures

NOTE: TriMark hoop strikes are designed and tested to meet or exceed FMVSS 206 (ECE R11) safety requirements only when used with TriMark's corresponding FMVSS 206 (ECE R11) compliant latches.

Individual part dimensions are for reference only. Refer to individual part drawings for complete dimensions, specifications, and installation procedures. Engineering assistance and application drawings are available.

For more information visit
www.trimarkcorp.com

